




WHEEL GUARDS



Install AME Wheel Guard

Install AME Wheel Guard

- Composite separator plate to be placed between the hub or drum and the wheel, and/or between two wheels in dual applications
- Provides protection for wheels against corrosion and excessive wear
- Stops rust, scale, salt and corrosion between steel disc rims in dual or single wheels
- Both aluminum and steel wheels can benefit from use of the Wheel Guard
- Prevents galvanic electrolysis between aluminum and steel wheels

| AME # | Alcoa # | Accuride # | Description | Stud Size | AME # | Alcoa # | Accuride # | Description | Stud Size |
|-------|---------|------------|------------------------------|-----------|-------|---------|------------|--------------------------|-----------|
| 61000 | 015000 | 5901 | 10 on 11 1/4" U.S. bus mount | 7/8" | 61040 | 013000 | 7381 | 10 on 335mm | 22mm |
| 61000 | 017000 | 5901 | 10 on 11 1/4" stud mount | 1 1/8" | 61040 | 018000 | 7381 | 10 on 335mm 32mm sleeved | 22mm |
| 61010 | 016000 | 5902 | 10 on 11 1/4" stud mount | 3/4" | 61050 | 012000 | 7902 | 8 on 275mm | 20mm |
| 61020 | 011000 | 5903 | 10 on 285.75mm hub piloted | 22mm | 61050 | 014000 | 7902 | 8 on 275mm | 22mm |



Distributed by:

